

Net Clip Conversion Kit

Installation Instructions

1" #8 brass Phillips wood screws are provided.

Measure your net handle thickness to assure the screws are not too long. If so, shorter screws can be found at most hardware stores.

With screws in the NetClip holes, place NetClip where you want it attached and press the screw heads firmly to mark for drilling.

Carefully drill pilot holes using a 1/8" bit marked with tape wrapped around the bit to prevent drilling through the handle.

Attach using a #2 Phillips head screwdriver.