

Third Magnet Conversion Kit Instructions

ITEMS INCLUDED (in 2 separate clamshells):

- 3-1/2" Magnet with Rubber Cover
- 4-3/8" Aluminum Extension Plate
- 3-1/4" Stainless Steel Bolt with Locknut
- 1/2" Bolt with Locknut
- 1" Bolts (2 are included to replace the original 7/8" Bolts)
- 7/8" White Washers (6 are included)


Carefully remove the 3/8" plug from the top center of the rod transport frame using your fingernails or a knife blade.



Now remove and discard the 3" bolt holding the top and bottom frames together using a 3/16" hex driver. Be sure to remove and discard the locknut from the bottom section of the frame.



Remove both magnets using a 7/16" socket and a 5/32" hex wrench or bit.



Replace the 7/8" Bolts with the 1" Bolts provided and place 2 of the White Washers between the Bottom Frame and each Magnet (do not tighten yet).

Assemble the top and bottom frames and the Aluminum Plate using the 3-1/4" bolt and Locknut provided. Tighten firmly.



Attach the 3rd Magnet to the Aluminum Plate with the 1/2" Bolt and Locknut using 1 White Washer between.

Place the assembled unit on a flat surface to confirm that all three magnets lay flat.



Adjustment can be made by increasing or decreasing the number of White Washers used. Once adjusted, tighten the Magnet Bolts firmly.

Contact Information:

9014 South Gary Ave., Tulsa, OK 74137-3313
Ph: 918-706-4396 - Fax: 918-299-2712
E-mail: flyrodholder@aol.com

